






SLACK ADJUSTER FITTING INSTRUCTIONS















Torque Values		
T1	Thread	Thread
	1/4" or M6	5/16" or M8
	3/8" or M10	
	6 - 8 ft. lbs (8 - 10Nm)	11 - 15 ft. lbs (15 - 20Nm)
		22 - 26 ft. lbs (30 - 35Nm)
T2	133 - 155 ft. lbs (180 - 210Nm)	
T3	40 - 50 ft. lbs (54 - 68Nm)	





* The contents of the kit indicate the parts to be replaced.

* A typical installation is shown, unless A, B, C or D are displayed



S-ASA



ASA

